

DT-1U1HQ/1Q-X

PINOUT DIAGRAM

OPTICAL PORT (ST)

STATUS INDICATORS

PWR - POWER (GREEN)
 DIAG - NA
 TX L - TX LASER ERROR (RED)
 RX OS - RX OPTICAL SIGNAL (GREEN)
 RX C - RX LINK (GREEN)

USB DEVICE (PORT 1) (TYPE A)

STATUS INDICATORS

OC -OVER CURRENT (RED)
 DE -PORT ENABLE (GREEN)

USB DEVICE (PORT 2) (TYPE A)

STATUS INDICATORS

OC -OVER CURRENT (RED)
 DE -PORT ENABLE (GREEN)

USB DEVICE (PORT 3) (TYPE A)


STATUS INDICATORS

OC -OVER CURRENT (RED)
 DE -PORT ENABLE (GREEN)

USB DEVICE (PORT 4) (TYPE A)

STATUS INDICATORS

OC -OVER CURRENT (RED)
 DE -PORT ENABLE (GREEN)



STATUS INDICATOR

PWR -POWER (GREEN)

VIDEO INPUT (CH.1)

STATUS INDICATORS

SYN -SYNC PRESENT (GREEN)
 VIDEO -VIDEO PRESENT (GREEN)
 / OVERLOAD (RED)

OPTICAL PORT ST (CH.1)

STATUS INDICATORS

TC/L - TX CARRIER (GREEN)
 /TX OVERLOAD (RED)

DR-1U1HQ/1Q-X

PINOUT DIAGRAM

OPTICAL PORT (ST)


STATUS INDICATORS

PWR - POWER (GREEN)
 DIAG - NA
 TX L - TX LASER ERROR (RED)
 RX OS - RX OPTICAL SIGNAL (GREEN)
 RX C - RX LINK (GREEN)

USB PC (TYPE B)

STATUS INDICATOR

USB -PORT ENABLE (GREEN)



STATUS INDICATOR

PWR -POWER (GREEN)

VIDEO OUTPUT (CH.1)

STATUS INDICATORS

SYN -SYNC PRESENT (GREEN)
 VIDEO -VIDEO PRESENT (GREEN)
 / OVERLOAD (RED)

OPTICAL PORT ST (CH.1)

STATUS INDICATORS

RC/E - RX OPTICAL SIGNAL (GREEN)
 /RX ERROR (RED)