





FOR RS-422 DATA MOVE SWITCH
2, 3, 4, 6, 8, 0 TO POSITION DOWN



FOR RS-422 DATA MOVE SWITCH
2, 3, 4, 6, 7, 8 TO POSITION DOWN