


DT-8AH-X

PINOUT DIAGRAM



* CARD DIAGNOSTIC IF APPLICABLE

MERIDIAN TECHNOLOGEIS INC.
700 ELMONT ROAD, ELMONT, N.Y. 11003
Support: 516-285-1000
support@meridian-tech.com
WWW.MERIDIAN-TECH.COM

DR-8AH-X

PINOUT DIAGRAM

STATUS INDICATORS

1. POWER (GREEN)
2. CARD DIAGNOSTIC*
(GREEN-OK / RED-ALLARM)

AUDIO OUTPUT (CH.1)

STATUS INDICATORS

1. AUDIO OUTPUT OVERLOAD (RED)
2. AUDIO OUTPUT PRESENT (GREEN)

AUDIO OUTPUT (CH.3)

STATUS INDICATORS

1. AUDIO OUTPUT OVERLOAD (RED)
2. AUDIO OUTPUT PRESENT (GREEN)

AUDIO OUTPUT (CH.5)


STATUS INDICATORS

1. AUDIO OUTPUT OVERLOAD (RED)
2. AUDIO OUTPUT PRESENT (GREEN)

AUDIO OUTPUT (CH.7)

STATUS INDICATORS

1. AUDIO OUTPUT OVERLOAD (RED)
2. AUDIO OUTPUT PRESENT (GREEN)



OPTICAL PORT

STATUS INDICATORS

1. RX OPTICAL SIGNAL (GREEN)/ABSENT (RED)
2. NA
3. RX CARRIER (GREEN)/ERROR (RED)

AUDIO OUTPUT (CH.2)

STATUS INDICATORS

1. AUDIO OUTPUT OVERLOAD (RED)
2. AUDIO OUTPUT PRESENT (GREEN)

AUDIO OUTPUT (CH.4)

STATUS INDICATORS

1. AUDIO OUTPUT OVERLOAD (RED)
2. AUDIO OUTPUT PRESENT (GREEN)

AUDIO OUTPUT (CH.6)

STATUS INDICATORS

1. AUDIO OUTPUT OVERLOAD (RED)
2. AUDIO OUTPUT PRESENT (GREEN)

AUDIO OUTPUT (CH.8)

STATUS INDICATORS

1. AUDIO OUTPUT OVERLOAD (RED)
2. AUDIO OUTPUT PRESENT (GREEN)

* CARD DIAGNOSTIC IF APPLICABLE

MERIDIAN TECHNOLOGIES INC.
700 ELMONT ROAD, ELMONT, N.Y. 11003
Support: 516-285-1000
support@meridian-tech.com
WWW.MERIDIAN-TECH.COM