

DXA-16D/16D-X

PINOUT DIAGRAM

STATUS INDICATORS

1. POWER (GREEN)
2. NA

STATUS INDICATORS

1. TX CARRIER (GREEN)/ERROR (RED)

DATA RS232 IN/OUT (PORT 1) (DB-9 FEMALE)

1. (CH.4) INPUT (CD)
2. (CH.1) OUTPUT (TD)
3. (CH.1) INPUT (RD)
4. (CH.2) INPUT (DTR)
5. GND
6. (CH.2) OUTPUT (DSR)
7. (CH.3) INPUT (RTS)
8. (CH.3) OUTPUT (CTS)
9. (CH.4) OUTPUT (RI)

DATA RS232 IN/OUT (PORT 2) (DB-9 FEMALE)


1. (CH.8) INPUT (CD)
2. (CH.5) OUTPUT (TD)
3. (CH.5) INPUT (RD)
4. (CH.6) INPUT (DTR)
5. GND
6. (CH.7) OUTPUT (DSR)
7. (CH.7) INPUT (RTS)
8. (CH.6) OUTPUT (CTS)
9. (CH.8) OUTPUT (RI)

DATA RS232 IN/OUT (PORT 3) (DB-9 FEMALE)

1. (CH.12) INPUT (CD)
2. (CH.9) OUTPUT (TD)
3. (CH.9) INPUT (RD)
4. (CH.10) INPUT (DTR)
5. GND
6. (CH.10) OUTPUT (DSR)
7. (CH.11) INPUT (RTS)
8. (CH.11) OUTPUT (CTS)
9. (CH.12) OUTPUT (RI)

DATA RS232 IN/OUT (PORT 4) (DB-9 FEMALE)

1. (CH.16) INPUT (CD)
2. (CH.13) OUTPUT (TD)
3. (CH.13) INPUT (RD)
4. (CH.14) INPUT (DTR)
5. GND
6. (CH.14) OUTPUT (DSR)
7. (CH.15) INPUT (RTS)
8. (CH.15) OUTPUT (CTS)
9. (CH.16) OUTPUT (RI)



OPTICAL PORT STATUS INDICATORS

1. NA
2. RX OPTICAL SIGNAL (GREEN)/ABSENT (RED)
3. RX CARRIER (GREEN)/ERROR (RED)

STATUS INDICATORS (PORT 1)

1. (CH.1) DATA INPUT
2. (CH.1) DATA OUTPUT
3. (CH.2) DATA INPUT
4. (CH.2) DATA OUTPUT
5. (CH.3) DATA INPUT
6. (CH.3) DATA OUTPUT
7. (CH.4) DATA INPUT
8. (CH.4) DATA OUTPUT

STATUS INDICATORS (PORT 2)

1. (CH.5) DATA INPUT
2. (CH.5) DATA OUTPUT
3. (CH.6) DATA INPUT
4. (CH.6) DATA OUTPUT
5. (CH.7) DATA INPUT
6. (CH.7) DATA OUTPUT
7. (CH.8) DATA INPUT
8. (CH.8) DATA OUTPUT

STATUS INDICATORS (PORT 3)

1. (CH.9) DATA INPUT
2. (CH.9) DATA OUTPUT
3. (CH.10) DATA INPUT
4. (CH.10) DATA OUTPUT
5. (CH.11) DATA INPUT
6. (CH.11) DATA OUTPUT
7. (CH.12) DATA INPUT
8. (CH.12) DATA OUTPUT

STATUS INDICATORS (PORT 4)

1. (CH.13) DATA INPUT
2. (CH.13) DATA OUTPUT
3. (CH.14) DATA INPUT
4. (CH.14) DATA OUTPUT
5. (CH.15) DATA INPUT
6. (CH.15) DATA OUTPUT
7. (CH.16) DATA INPUT
8. (CH.16) DATA OUTPUT

DXB-16D/16D-X

PINOUT DIAGRAM

STATUS INDICATORS

1. POWER (GREEN)
2. NA

STATUS INDICATORS

1. TX CARRIER (GREEN)/ERROR (RED)

DATA RS232 IN/OUT (PORT 1) (DB-9 FEMALE)

1. (CH.4) INPUT (CD)
2. (CH.1) OUTPUT (TD)
3. (CH.1) INPUT (RD)
4. (CH.2) INPUT (DTR)
5. GND
6. (CH.2) OUTPUT (DSR)
7. (CH.3) INPUT (RTS)
8. (CH.3) OUTPUT (CTS)
9. (CH.4) OUTPUT (RI)

DATA RS232 IN/OUT (PORT 2) (DB-9 FEMALE)


1. (CH.8) INPUT (CD)
2. (CH.5) OUTPUT (TD)
3. (CH.5) INPUT (RD)
4. (CH.6) INPUT (DTR)
5. GND
6. (CH.7) OUTPUT (DSR)
7. (CH.7) INPUT (RTS)
8. (CH.6) OUTPUT (CTS)
9. (CH.8) OUTPUT (RI)

DATA RS232 IN/OUT (PORT 3) (DB-9 FEMALE)

1. (CH.12) INPUT (CD)
2. (CH.9) OUTPUT (TD)
3. (CH.9) INPUT (RD)
4. (CH.10) INPUT (DTR)
5. GND
6. (CH.10) OUTPUT (DSR)
7. (CH.11) INPUT (RTS)
8. (CH.11) OUTPUT (CTS)
9. (CH.12) OUTPUT (RI)

DATA RS232 IN/OUT (PORT 4) (DB-9 FEMALE)

1. (CH.16) INPUT (CD)
2. (CH.13) OUTPUT (TD)
3. (CH.13) INPUT (RD)
4. (CH.14) INPUT (DTR)
5. GND
6. (CH.14) OUTPUT (DSR)
7. (CH.15) INPUT (RTS)
8. (CH.15) OUTPUT (CTS)
9. (CH.16) OUTPUT (RI)



OPTICAL PORT STATUS INDICATORS

1. NA
2. RX OPTICAL SIGNAL (GREEN)/ABSENT (RED)
3. RX CARRIER (GREEN)/ERROR (RED)

STATUS INDICATORS (PORT 1)

1. (CH.1) DATA INPUT
2. (CH.1) DATA OUTPUT
3. (CH.2) DATA INPUT
4. (CH.2) DATA OUTPUT
5. (CH.3) DATA INPUT
6. (CH.3) DATA OUTPUT
7. (CH.4) DATA INPUT
8. (CH.4) DATA OUTPUT

STATUS INDICATORS (PORT 2)

1. (CH.5) DATA INPUT
2. (CH.5) DATA OUTPUT
3. (CH.6) DATA INPUT
4. (CH.6) DATA OUTPUT
5. (CH.7) DATA INPUT
6. (CH.7) DATA OUTPUT
7. (CH.8) DATA INPUT
8. (CH.8) DATA OUTPUT

STATUS INDICATORS (PORT 3)

1. (CH.9) DATA INPUT
2. (CH.9) DATA OUTPUT
3. (CH.10) DATA INPUT
4. (CH.10) DATA OUTPUT
5. (CH.11) DATA INPUT
6. (CH.11) DATA OUTPUT
7. (CH.12) DATA INPUT
8. (CH.12) DATA OUTPUT

STATUS INDICATORS (PORT 4)

1. (CH.13) DATA INPUT
2. (CH.13) DATA OUTPUT
3. (CH.14) DATA INPUT
4. (CH.14) DATA OUTPUT
5. (CH.15) DATA INPUT
6. (CH.15) DATA OUTPUT
7. (CH.16) DATA INPUT
8. (CH.16) DATA OUTPUT