

DXA-1A8C1F/1A8C1F-x

PIN-OUT DIAGRAM

STATUS INDICATORS

1. POWER (GREEN)
2. NA

STATUS INDICATORS

1. TX CARRIER (GREEN)/ERROR (RED)

AUDIO IN/OUT (PORT 1)

DB-9 FEMALE

1. (CH.1) OUTPUT-
2. (CH.1) OUTPUT+
3. N/A
4. N/A
5. GND
6. (CH.1) INPUT-
7. (CH.1) INPUT+
8. N/A
9. N/A

CONTACT IN/OUT (PORT 2, PORT 3)

(PORT 2)

HD-15 FEMALE

1. (CH.1) INPUT
2. (CH.2) INPUT
3. (CH.3) INPUT
4. (CH.4) INPUT
5. GND
6. (CH.1) OUTPUT
7. (CH.1) OUTPUT
8. (CH.2) OUTPUT
9. (CH.2) OUTPUT
10. (CH.3) OUTPUT
11. (CH.3) OUTPUT
12. (CH.4) OUTPUT
13. (CH.4) OUTPUT
14. N/A
15. N/A

(PORT 3)


HD-15 FEMALE

1. (CH.5) INPUT
2. (CH.6) INPUT
3. (CH.7) INPUT
4. (CH.8) INPUT
5. GND
6. (CH.5) OUTPUT
7. (CH.5) OUTPUT
8. (CH.6) OUTPUT
9. (CH.6) OUTPUT
10. (CH.7) OUTPUT
11. (CH.7) OUTPUT
12. (CH.8) OUTPUT
13. (CH.8) OUTPUT
14. N/A
15. N/A

DATA RS422 IN/OUT (PORT 4)

DB-9 FEMALE

1. (CH.1) INPUT +
2. (CH.1) INPUT -
3. N/A
4. N/A
5. GND
6. (CH.1) OUTPUT +
7. (CH.1) OUTPUT -
8. N/A
9. N/A



OPTICAL PORT STATUS INDICATORS

1. NA
2. RX OPTICAL SIGNAL (GREEN)/ABSENT (RED)
3. RX CARRIER (GREEN)/ERROR (RED)

STATUS INDICATORS

(PORT 1) AUDIO

1. (CH.1) AUDIO INPUT PRESENT
2. (CH.1) AUDIO INPUT OVERLOAD
3. N/A
4. N/A
5. (CH.1) AUDIO OUTPUT PRESENT
6. (CH.1) AUDIO OUTPUT OVERLOAD
7. N/A
8. N/A

(PORT 2) CONTACT CLOSURE

1. (CH.1) INPUT PRESENT
2. (CH.1) OUTPUT PRESENT
3. (CH.2) INPUT PRESENT
4. (CH.2) OUTPUT PRESENT
5. (CH.3) INPUT PRESENT
6. (CH.3) OUTPUT PRESENT
7. (CH.4) INPUT PRESENT
8. (CH.4) OUTPUT PRESENT

(PORT 3) CONTACT CLOSURE

1. (CH.1) INPUT PRESENT
2. (CH.1) OUTPUT PRESENT
3. (CH.2) INPUT PRESENT
4. (CH.2) OUTPUT PRESENT
5. (CH.3) INPUT PRESENT
6. (CH.3) OUTPUT PRESENT
7. (CH.4) INPUT PRESENT
8. (CH.4) OUTPUT PRESENT

(PORT 4) RS-422 DATA

1. (CH.1) DATA INPUT
2. N/A
3. N/A
4. N/A
5. N/A
6. (CH.1) DATA OUTPUT
7. N/A
8. N/A

DXB-1A8C1F/1A8C1F-x

PIN-OUT DIAGRAM

STATUS INDICATORS

1. POWER (GREEN)
2. NA

STATUS INDICATORS

1. TX CARRIER (GREEN)/ERROR (RED)

AUDIO IN/OUT (PORT 1)

DB-9 FEMALE

1. (CH.1) OUTPUT-
2. (CH.1) OUTPUT+
3. N/A
4. N/A
5. GND
6. (CH.1) INPUT-
7. (CH.1) INPUT+
8. N/A
9. N/A

CONTACT IN/OUT (PORT 2, PORT 3)

(PORT 2) HD-15 FEMALE

1. (CH.1) INPUT
2. (CH.2) INPUT
3. (CH.3) INPUT
4. (CH.4) INPUT
5. GND
6. (CH.1) OUTPUT
7. (CH.1) OUTPUT
8. (CH.2) OUTPUT
9. (CH.2) OUTPUT
10. (CH.3) OUTPUT
11. (CH.3) OUTPUT
12. (CH.4) OUTPUT
13. (CH.4) OUTPUT
14. N/A
15. N/A


(PORT 3) HD-15 FEMALE

1. (CH.5) INPUT
2. (CH.6) INPUT
3. (CH.7) INPUT
4. (CH.8) INPUT
5. GND
6. (CH.5) OUTPUT
7. (CH.5) OUTPUT
8. (CH.6) OUTPUT
9. (CH.6) OUTPUT
10. (CH.7) OUTPUT
11. (CH.7) OUTPUT
12. (CH.8) OUTPUT
13. (CH.8) OUTPUT
14. N/A
15. N/A

DATA RS422 IN/OUT (PORT 4)

DB-9 FEMALE

1. (CH.1) OUTPUT +
2. (CH.1) OUTPUT -
3. N/A
4. N/A
5. GND
6. (CH.1) INPUT +
7. (CH.1) INPUT -
8. N/A
9. N/A



OPTICAL PORT STATUS INDICATORS

1. NA
2. RX OPTICAL SIGNAL (GREEN)/ABSENT (RED)
3. RX CARRIER (GREEN)/ERROR (RED)

STATUS INDICATORS

(PORT 1) AUDIO

1. (CH.1) AUDIO INPUT PRESENT
2. (CH.1) AUDIO INPUT OVERLOAD
3. N/A
4. N/A
5. (CH.1) AUDIO OUTPUT PRESENT
6. (CH.1) AUDIO OUTPUT OVERLOAD
7. N/A
8. N/A

(PORT 2) CONTACT CLOSURE

1. (CH.1) INPUT PRESENT
2. (CH.1) OUTPUT PRESENT
3. (CH.2) INPUT PRESENT
4. (CH.2) OUTPUT PRESENT
5. (CH.3) INPUT PRESENT
6. (CH.3) OUTPUT PRESENT
7. (CH.4) INPUT PRESENT
8. (CH.4) OUTPUT PRESENT

(PORT 3) CONTACT CLOSURE

1. (CH.1) INPUT PRESENT
2. (CH.1) OUTPUT PRESENT
3. (CH.2) INPUT PRESENT
4. (CH.2) OUTPUT PRESENT
5. (CH.3) INPUT PRESENT
6. (CH.3) OUTPUT PRESENT
7. (CH.4) INPUT PRESENT
8. (CH.4) OUTPUT PRESENT

(PORT 4) RS-422 DATA

1. N/A
2. (CH.1) DATA OUTPUT
3. N/A
4. N/A
5. (CH.1) DATA INPUT
6. N/A
7. N/A
8. N/A