

TRANSMITTER FRONT PANEL

ST-16HD-x


ST-16HG-x

OPTICAL PORT COMMON OUT
OPTICAL PORT EXPANSION IN
(ST, FC)

VIDEO INPUT
(CH.1-CH.8)

STATUS INDICATORS

PWR -POWER (GREEN)
DIAG -NA
TX -NA
RX -NA
1 SIGNAL PRESENT (GREEN)
2 - LASER ON (GREEN)



OPTICAL PORT OUT
(ST, FC)

VIDEO INPUT
(CH.1-CH.8)

ST-8HD-xX + ST-8HD-x


OR

ST-8HG-xX + ST-8HG-x

RECEIVER FRONT PANEL

SR-16HD-x

SR-16HG-x



CONNECTION DIAGRAM

SR-16HD-X
SR-16HG-X

ST-16HD-X
ST-16HG-X

