


ST-4V-X

PINOUT DIAGRAM



OPTICAL PORT

STATUS INDICATORS

PWR -POWER (GREEN)
 DIAG -NA
 TX C/L -TX CARRIER (GREEN)/OVERLOAD (RED)
 RX C/E -NA

VIDEO INPUT (CH.1)

STATUS INDICATORS

SYN -SYNC PRESENT (GREEN)
 VIDEO -VIDEO PRESENT (GREEN)/OVERLOAD (RED)

VIDEO INPUT (CH.2)

STATUS INDICATORS

SYN -SYNC PRESENT (GREEN)
 VIDEO -VIDEO PRESENT (GREEN)/OVERLOAD (RED)

VIDEO INPUT (CH.3)

STATUS INDICATORS

SYN -SYNC PRESENT (GREEN)
 VIDEO -VIDEO PRESENT (GREEN)/OVERLOAD (RED)


VIDEO INPUT (CH.4)

STATUS INDICATORS

SYN -SYNC PRESENT (GREEN)
 VIDEO -VIDEO PRESENT (GREEN)/OVERLOAD (RED)

SR-4V-X

PINOUT DIAGRAM



OPTICAL PORT

STATUS INDICATORS

PWR -POWER (GREEN)
 DIAG -NA
 TX C/L -RX CARRIER (GREEN)/ERROR (RED)
 RX C/E -NA

VIDEO OUTPUT (CH.1)

STATUS INDICATORS

SYN -SYNC PRESENT (GREEN)
 VIDEO -VIDEO PRESENT (GREEN)/OVERLOAD (RED)

VIDEO OUTPUT (CH.2)

STATUS INDICATORS

SYN -SYNC PRESENT (GREEN)
 VIDEO -VIDEO PRESENT (GREEN)/OVERLOAD (RED)

VIDEO OUTPUT (CH.3)

STATUS INDICATORS

SYN -SYNC PRESENT (GREEN)
 VIDEO -VIDEO PRESENT (GREEN)/OVERLOAD (RED)

VIDEO OUTPUT (CH.4)

STATUS INDICATORS

SYN -SYNC PRESENT (GREEN)
 VIDEO -VIDEO PRESENT (GREEN)/OVERLOAD (RED)